



INSTALLATION AND OWNER'S MANUAL

TAPER END CAP Z4011

for use with Z4010 R1200 C / CL EXHAUST



Rubber Malet
Hex Key Wrench, 3mm

NOTE: Right and Left side of Motorcycle is determined while sitting on the bike.

PARTS LIST

Index	Part No.	Description	Qty.
1	40-4000013-000	End Cap	2
Bag 406			
2	51-516508-000	Screws, Button Head	4



PREPARATION

1. Position the motorcycle securely on its side stand or a work stand.
2. Remove the two M5 x 8 screws holding the slash tip to the muffler (hex key wrench, 3mm). Repeat on other side.
3. Pull the slash tip end cap from the Z4010 exhaust muffler. The rubber malet may be useful in getting the end cap to slide off the muffler. Gently tap around end cap while pulling on the tip. Repeat on other side.

INSTALLATION

1. Install the Taper End Caps onto the outlet ends of the Z-Technik Muffler Assembly. The rubber malet may be useful in getting the end cap on the muffler. Secure each end cap with two M5 x 8 screws (hex key wrench, 3mm).

